

ASSEMBLY INSTRUCTIONS

MODEL#: RL1009

NOTE: Only the technical personnel can be allowed to fix and maintain.

IMPORTANT!

Make sure that the power is switch off at the electricity mains supply before commencing work.

INSTALLATION INSTRUCTIONS

Open parts according to the bag as shown in figure II shows, installed on the wall or ceiling, and should be fixed to the ceiling in the right place. Ground Connection (See picture 1): there are one tapping hole & two samples.

Connect the supply ground wire (2) on the green ground screw (15) and then put into the tapping hole.

Connect the fixture ground wire (3) with supply ground wire (2) by connecting terminal (12). Caution: DO NOT connect ground wire with supply power wire.

Connect fixture supply wire with power supply wire. Caution: Remember distinguish the positive and negative charges. (See picture 2)

Push canopy up to the ceiling and Lock out the nut.

REPLACEMENT BULB

Do not exceed the maximum wattage.

Light bulbs recommended: RL1009 - 1*E12*60W 5-GU10*60W Max. Type B.

CLEANING CARE

Clean with a soft dry cloth.

SAFETY INFORMATION

Lamp used must in rated voltage, and do not touch the bulb with bare hands. Always switch off the electricity supply and allow to cool for 10 minutes before changing the light bulbs.

If the external cables have been damaged, Pls change or repair by manufacturer or service agency or professional electrician. In order to avoid the danger.

